



## Mounting Instructions:

Remove old bars.

To avoid the possibility of fracturing/breaking the new bar(s), install as follows:

- Place bar on your rotor, if the bar has some rocking, insert washer(s) between stand off and bar before tightening
- Torque all bolts to 95-105 foot pounds

Part	Quantity
K 4017	1
Fender Washer	2
Customer specific bolt (nut)	2

