



CLEAR VIEW® CAPS- K CVC CP3777-20 Kit

INSTALLATION INSTRUCTIONS

- Remove OEM Cap.
- Remove O-ring and allow oil to completely drain.
- Inspect o-ring groove in hub.
- Install o-ring in hub groove, place gasket on cap and bolt clear cap(with gasket) to the hub and tighten bolts to 40-50 inch pounds.
- Replace oil in hub to manufacturer's specifications.
- Tighten plugs with plug wrench.

Use only soap and water to clean caps, no solvents (solvents can cause clouding and premature failure of caps). Solvent use will void warranty

PARTS LIST:



K CP3777	Kile® Clear View® Cap	20
O ring 126	Camo O-ring	20
K 3777-G	Gasket	20
K 1215	Cap Plug	40
K 1216	Plug Wrench	1
6Mx18	Bolt	120

Kile® Clear

View® Caps are covered by one or more of the following US Patent numbers: D666,227; #D689,108; #D699,772; #D700,227; #8,684,474; #8,833,872; #8,979,215; #9,120,514; #9,399,369; #9,458,965

