



CLEAR VIEW® CAPS- K CVC CP3777-24 Kit

INSTALLATION INSTRUCTIONS

- Remove OEM Cap.
- Remove O-ring and allow oil to completely drain.
- Inspect o-ring groove in hub.
- Install o-ring in hub groove, place gasket on cap and bolt clear cap(with gasket) to the hub and tighten bolts to 40-50 inch pounds.
- Replace oil in hub to manufacturer's specifications.
- Tighten plugs with plug wrench.

*Use only soap and water to clean caps, no solvents (solvents can cause clouding and premature failure of caps).
Solvent use will void warranty*

PARTS LIST:



K CP3777	Kile® Clear View® Cap	24
O ring 126	Camo O-ring	24
K 3777-G	Gasket	24
K 1215	Cap Plug	48
K 1216	Plug Wrench	1
6Mx18	Bolt	144

Kile® Clear

View® Caps are covered by one or more of the following US Patent numbers: D666,227; #D689,108; #D699,772; #D700,227; #8,684,474; #8,833,872; #8,979,215; #9,120,514; #9,399,369; #9,458,965

