



CLEAR VIEW® CAP Kit-CTS

Tracked Axial-Flow Combine
(equipped with rubber tracks)
Combine Models: 7010,7120,8010,8120,9120,7230,8230,9230

INSTALLATION INSTRUCTIONS

- Remove original Case IH cap and allow oil to completely drain.
- Remove O-ring.
- Clean o-ring, housing & snap ring groove.
- Lightly oil O-ring before installing, install clear cap and secure snap ring.
- Replace lubricant in hub to manufacturer's specifications.
- Install plug. Tighten with plug wrench.

*Use only soap and water to clean caps, no solvents (solvents can cause clouding and premature failure of caps).
Solvent use will void warranty*

PARTS LIST:

Part#	Desc	Qty
K-8740-R2	Roller Cap	12
K-8743-I2	Idler Cap	8
K-1215P & K012POR	Plug	20
K-012-POR	Plug O-ring(installed)	20
K-5426-IOR	Idler O-ring	8
K-4140-ROR	Roller O-ring	12
K-1216-W	Plug Wrench	1
	Installation Instructions	1

Kile® Clear View® Caps are covered by one or more of the following US Patent numbers: D666,227; #D689,108; #D699,772; #D700,227; #8,684,474; #8,833,872; #8,979,215; #9,120,514; #9,399,369; #9,458,965

