

INSTALLATION INSTRUCTIONS

- Remove OEM Cap.
- Remove O-ring and allow oil to completely drain.
- Inspect & clean present o-ring, if damaged, flattened or not acceptable for reuse, replace.
- Lightly oil O-ring before installing, bolt clear cap to the hub and tighten bolts to 40-50 inch pounds.
- Replace oil in hub to manufacturer's specifications.

Use only soap and water to clean caps, no solvents (solvents can cause clouding and premature failure of caps). Solvent use will void warranty

PARTS LIST:

Part	Desc	Qty	
K 7120-GT	Kile Clear View Cap	20	
K GT047	K047 Oring	20	
K GT161	K161 Oring	20	

